
1/5 GRANDAIS



FR9 2000 0075




FIGURE 2

300 start SDT 302 user rinformation entry and checking authorizations -304 maintenance operations entry 307_ and authorization checking N abort 305 checking OK? command 309 seize&store maintenance operations -311 seize & store system, peripheral, delay and restart parameters 313 compute the delay & activate the DELAY system service 315 Display a WAIT message on the operator console 317 delay expired? 319 321 Initialize peripherals abort 320 init OK? command set system in restricted mode 327. N restricted mode abort and OK? power OFF power ON FIGURE 3B

FIGURE 3A

GRANDAIS




FIGURE 3B




FIGURE 4